

Fitting Guide for Ford Transit

Mirror Glass

There is no need to remove the mirror from your van

Don't forget to wear PPE



1. Tilt the mirror glass upwards

2. Gently lift the glass at the bottom until it pops off



3. If required remove heating elements





4. Once the heating elements are attached (if needed), line the glass up with the backing plate

5. Press down firmly until it clicks



6. Check the glass moves freely and that it isn't loose. Wipe the glass to get rid of any marks



Next Day
Delivery



Vehicle Registration
Look Up



30,000+
Parts in Stock

