

Fitting Guide for Ford Transit MK8

There is no need to remove the mirror from your van

Mirror Glass

Don't forget to wear PPE



2. Gently lift the glass at the bottom until it pops off

1. Tilt the mirror glass upwards



3. If required remove heating elements



4. Once the heating elements are attached (if needed), line the glass up with the backing plate



5. Press down firmly until it clicks



8. Check the glass moves freely and that it isn't loose. Wipe the glass to get rid of any marks

For the lower mirror glass:

6. Gently lift the glass at the top until it pops off



7. Press down firmly until it clicks



Next Day Delivery



Vehicle Registration Look Up



30,000+ Parts in Stock

