

Fitting Guide for Ford Transit MK8

There is no need to remove the mirror from your van

Mirror Cover

Don't forget to wear PPE

You may have to remove the mirror glass in order to take the original cover off. See our fitting guide on how to do this



1. Once the mirror glass is removed, carefully pry the clips out of position and pull the mirror cover off.



2. Match the clips up with the holes in the back of the mirror unit





3. Position the cover onto the mirror unit making sure to line up all of the clips

4. When all clips are lined up, push firmly until you hear a click



5. Wipe the cover to get rid of any marks and replace the mirror glass

Next Day
Delivery



Vehicle Registration
Look Up



30,000+
Parts in Stock

